

Sets for Sony Venice

Basic Set for Sony Venice

- Consists of:
- Plate For Sony Venice K2.0017137
 - Bridge Plate Adapter BPA-5 K2.0017138
 - Support Rods 340 mm (13.4 inch), Ø 15 mm K2.66252.0
 - Quick Release Plate, QRP-1 K2.0000399



[KK.0017141](#)

Pro Set for Sony Venice

- Consists of:
- Plate For Sony Venice K2.0017137
 - Bridge Plate Adapter BPA-5 K2.0017138
 - Top Plate For Sony Venice K2.0017024
 - Camera Center Handle CCH-4 K2.0017270
 - Rod mounting bracket RMB-3 K2.0006186
 - Support Rods 340 mm (13.4 inch), Ø 15 mm K2.66252.0
 - Quick Release Plate, QRP-1 K2.0000399
 - Sliding Adapter for CCH-4 K2.0019282



[KK.0017142](#)

EVF bracket Set for Sony DVF-EL200

- Consists of:
- EVF bracket for Sony DVF-EL200 (Venice) K2.021525
 - Mini Viewfinder Bracket MVB-1 K2.006140



[KK.0022326](#)



Plate For Sony Venice
[K2.0017137](#)



Top Plate For Sony Venice
[K2.0017024](#)



Bridge Plate Adapter
BPA-5, [K2.0017138](#)



Camera Center Handle
CCH-4, [K2.0017270](#)



Sliding Adapter for CCH-4
[K2.0019282](#)



EVF bracket for Sony DVF-
EL200 (Venice), [K2.021525](#)

Venice Extension Unit Set Basic

- Consists of:
- Base Plate for Venice Ext. Unit K2.0024564
 - Top Plate for Venice Ext. Unit K2.0024565
 - Side Bracket Right for Venice Ext. Unit K2.0024566
 - Side Bracket Left for Venice Ext. Unit K2.0024761
 - Cable Clamp for Venice Ext. Unit K2.0024569
 - Back Plate for Venice Ext. Unit K2.0024573
 - Rosette Adapters, RA-6, pair K2.0024574



[KK.0024806](#)

Venice Extension Unit Set Pro

- Consists of:
- Base Plate for Venice Ext. Unit K2.0024564
 - Top Plate for Venice Ext. Unit K2.0024565
 - Side Bracket Right for Venice Ext. Unit K2.0024566
 - Side Bracket Left for Venice Ext. Unit K2.0024761
 - Cable Clamp for Venice Ext. Unit K2.0024569
 - Back Plate for Venice Ext. Unit K2.0024573
 - Rosette Adapters, RA-6, pair K2.0024574
 - Cage Top Handle, CTH-1 K2.66227.0
 - 15mm LWS Rod Console K2.65264.0
 - Rod Mounting Bracket RMB-3 K2.0006186
 - 15mm Reduction Insert K2.66255.0
 - Support Rods 140mm, 5.5in, Ø15mm K2.66254.0
 - Support Rods 240mm/9.4in, Ø15mm K2.66253.0
 - Wooden Handgrip WHG-1 K2.0024965



Base Plate for Venice Ext.
Unit, [K2.0024564](#)



Top Plate for Venice Ext.
Unit, [K2.0024565](#)



Back Plate for Venice Ext.
Unit, [K2.0024573](#)



Side Bracket Left for Veni-
ce Ext. Unit, [K2.0024761](#)



Side Bracket Right for Ve-
nice Ext. Unit, [K2.0024566](#)



Cable Clamp for Venice
Ext. Unit, [K2.0024569](#)

Sets for Sony F5 / F55

Basic Set for Sony PMW F5/F55 LWS

- Consists of:
- Adapter Plate for Sony PMW F5/F55 K2.66246.0
 - Support Rods 240mm Ø 15mm K2.66253.0
 - Shoulder Pad for Sony PMW F5/F55 K2.66249.0



[KK.0005798](#)

Pro Set for Sony PMW F5/F55 LWS

- Consists of:
- Adapter Plate for Sony PMW F5/F55 K2.66246.0
 - Support Rods 240mm Ø 15mm K2.66253.0
 - Shoulder Pad for Sony PMW F5/F55 K2.66249.0
 - Top Plate for Sony PMW F5/F55 K2.66247.0
 - Viewfinder Adapter for F5/F55, VFA-1 K2.66248.0
 - Center Camera Handle, CCH-2 K2.73002.0
 - Viewfinder Plug Protection for F5/F55 K2.66251.0

Set for Sony PMW F5/F55 + BP-8

- Consists of:
- Adapter Plate for Sony PMW F5/F55 K2.66246.0
 - Support Rods 240mm Ø 15mm K2.66253.0
 - Shoulder Pad for Sony PMW F5/F55 K2.66249.0
 - Top Plate for Sony PMW F5/F55 K2.66247.0
 - Viewfinder Adapter for F5/F55, VFA-1 K2.66248.0
 - Center Camera Handle, CCH-2 K2.73002.0
 - Bridge Plate BP-8 Set (19mm Rods) K2.47090.0
 - Viewfinder Plug Protection for F5/F55 K2.66251.0

Set for Sony PMW F5/F55 + BP-9

- Consists of:
- Adapter Plate for Sony PMW F5/F55 K2.66246.0
 - Support Rods 240mm Ø 15mm K2.66253.0
 - Shoulder Pad for Sony PMW F5/F55 K2.66249.0
 - Top Plate for Sony PMW F5/F55 K2.66247.0
 - Viewfinder Adapter for F5/F55, VFA-1 K2.66248.0
 - Center Camera Handle, CCH-2 K2.73002.0
 - Bridge Plate BP-9 Set (15mm Rods) K2.47091.0
 - Viewfinder Plug Protection for F5/F55 K2.66251.0

Broadcast Plate Set for Sony PMW F5/F55

- Consists of:
- Broadcast Plate for Sony PMW F5/F55 K2.66261.0
 - Shoulder Pad for Sony PMW F5/F55 K2.66249.0
 - 15mm Rods 240 mm K2.66253.0

Pro Broadcast Plate Set for Sony F5/F55

- Consists of:
- Broadcast Plate for Sony PMW F5/F55 K2.66261.0
 - Shoulder Pad for Sony PMW F5/F55 K2.66249.0
 - 15mm Rods 240 mm K2.66253.0
 - Top Plate for Sony PMW F5/F55 K2.66247.0
 - Viewfinder Adapter for F5/F55, VFA-1 K2.66248.0
 - Center Camera Handle, CCH-2 K2.73002.0
 - Viewfinder Plug Protection for F5/F55 K2.66251.0

Set Rosettes for Broadcast Sony/ULB-4

- Consists of:
- Rosette for Broadcast Plate/ULB-4 (2x) K2.47639.0

Accessories for Sony F5 / F55

Adapter Plate for Sony PMW F5/F55, [K2.66246.0](#)



Broadcast Plate for Sony PMW F5/F55, [K2.66261.0](#)



Shoulder Pad for Sony PMW F5/F55, [K2.66249.0](#)



Top Plate for Sony PMW F5/F55 [K2.66247.0](#)



Camera Center Handle CCH-2, [K2.73002.0](#)



Viewfinder Adapter for F5/F55 (VFA-1), [K2.66248.0](#)




Viewfinder Plug Protection for Sony PMW F5/F55 [K2.66251.0](#) (excl. Top Plate)



Microphone Holder Bracket MHB-1, [K2.66256.0](#)



Rosette for Broadcast Plate, ULB-4, [K2.47639.0](#)



Shoulder Belt Adapters SBA-1 [K2.0001223](#)



Bracket for Sony AXSR7 Recorder, [K2.0013401](#)



Handgrip on/off for Sony F5/F55, [K2.66278.0](#) (RS-4 Pin) Spare Cable for Handgrip



For Sony FS-700

Handgrip Adapter HGA-2 for Sony FS-700, [K2.66210.0**](#)



Handgrip Adapter HGA-2 for Sony FS-700 handgrip. Convert the Sony Rosette with 1/4" thread to ARRI Standard

**** discontinued items
no stock available anymore**